


## 10 STEP WiFi Baby™ Quickstart Guide



**FOR EASIEST SETUP, PLEASE USE THIS QUICKSTART GUIDE  
WITH VIDEO & SCREEN SHOT GUIDES AT WIFIBABY.NET>SUPPORT**

**SAFETY WARNING --STRANGULATION HAZARD: CPSC.gov – “Keep cord out of baby’s reach. NEVER place camera or cords within 3 feet of crib or playing area. Only use the AC Adapter provided.”**


1. Use included Mac/PC setup CD-ROM or download setup software from wifibaby.net homepage sidebar. Keep setup software icon on desktop.




2. Remove plastic film from lens, attach stand, use screwdriver or coin to tighten, connect AC adaptor and Ethernet cable to camera.



3. Plug camera into power and Ethernet cable to wireless router **NOT your PC or Mac**. Once camera is connected to router the green power light will blink amber.



4. Click setup software icon. It will search for your camera on your network. Click REFRESH if camera does not appear right away. **If using Mac and camera does not appear, see "Mac Setup 1.4 Software: Troubleshooting" under SUPPORT at wifibaby.net.**
5. Highlight camera, Click SETUP. For username / password use admin / 1234.
6. Choose "Obtain IP address automatically" and "Obtain DNS server automatically" and click OK. Highlight and click OPEN. **Use all default settings; a static IP can be used later if needed.** Note your IP address. (IP info in screen shot below only an example, your IP will vary.)



The screenshot shows a window titled "SetUp 10.0.1.200" with two main sections: "Basic Information" and "Network Information".

**Basic Information:**

- Device Name: WiFi Baby
- Location: Default Location
- Http Port: 80

**Network Information:**

- ☒ Obtain an IP address automatically
- ☐ Use the following IP address
- IP Address: 10.0.1.200
- Subnet Mask: 255.255.255.0
- Default Gateway: 10.0.1.1
- ☒ Obtain DNS server address automatically
- ☐ Use the following DNS Server address
- Primary DNS Server Address: 10.0.1.1
- Secondary DNS Server Address: (empty field)

At the bottom are "OK" and "Cancel" buttons.

7. Your default web browser will now open to the sign in screen. Bookmark your IP address on your browser. Click SETTINGS. For best performance, we highly recommend using Explorer for PC, Firefox for Mac or **download our “Multi Cam Viewer” for PC/Mac from wifibaby.net homepage sidebar.**

8. Before using the Wizard **it is useful to know your router’s wireless password encryption type – WEP, WPA or WPA2.** If you have WPA or WPA2 your security mode will be determined automatically by the Wizard and you can dismiss the following message:

If you have WEP and are unsure if your WEP security mode is WEP64bit or WEP128bit, or if the WEP key type is Hex or ASCII, there is a simple rule of thumb where:

If your WEP password is 5 characters = WEP 64-bit ASCII  
If your WEP password is 10 characters = WEP 64-bit HEX  
If your WEP password is 13 characters = WEP 128-bit ASCII  
If your WEP password is 26 characters = WEP 128-bit HEX

9. Click WIZARD located on the top right of settings screen. Give your camera a name, “high” for picture quality, pick time zone, scan for available wireless networks. A list of networks will appear. Select yours, enter your wireless password, correct encryption type -WEP, WPA, WPA2- and choose AUTOMATIC for IP.

Select one wireless device.

No.	SSID	Mode	Encrypt
1	WIFI BABY	Infra	WPA2-PS

1

Welcome  
Camera Setup  
Date & Time  
**Wlan setup**  
IP setup  
Finish

Wireless WPA-PSK Settings.

Security mode: ☐ WPA-PSK ☒ WPA2-PSK

Encryption type: ☐ TKIP ☒ AES

WPA key:

Re-type key:

Welcome  
Camera Setup  
Date & Time  
**Wlan setup**  
IP setup  
Finish

10. Click FINISH and wait 30 seconds for the camera to reboot. Unplug camera from power and Ethernet and plug it back in without an Ethernet connection. Go back to your bookmarked IP address on your browser. Click Live View on the sign in screen and enter admin / 1234. **Enter same IP/password into the apps.** To change your default password and add other users go under SETTINGS>TOOLS>USER MANAGEMENT.

The setup procedure is almost complete. Please check the settings below and if they seem correct, click Finish.

Camera name : WiFi Baby  
Picture of quality: High  
Timezone : GMT-05:00  
Wireless setting:  
Mode: Infrastructure  
SSID: WIFI BABY  
Encryption: WPA2-PSK  
Type of obtain ip: Manual  
IP address: 10.0.1.200  
Netmask: 255.255.255.0  
Gateway: 10.0.1.1

Welcome  
Camera Setup  
Date & Time  
Wlan setup  
IP setup  
Finish

Previous

Finish

Close

**Audio on Mobile Apps: Make sure audio is on 5.9 AMR Bit Rate on camera under SETTINGS> CAMERA>CAMERA SETUP>AMR BIT RATE.**

**3-5 second audio/video delay from “live” is normal. Reason: Buffering time between camera and receiver.**

**You are now wireless!**

**Visit [WIFIBABY.NET](http://WIFIBABY.NET) > SUPPORT for video setup guides for apps and camera.**

**Setup Issues? It is usually an incorrect wireless password, encryption type or you may need a static IP address for your camera.**

**Please visit [WIFIBABY.NET](http://WIFIBABY.NET) > SUPPORT for Troubleshooting Tips or call us to schedule phone or screen share support at 855-943-4367.**

